

****ATTENTION LOADING INFORMATION****

TIWAG charging station

1. **CHARGING PLUG** on the car & plug into the charging station
2. then hold the TIWAG charging card, which you will find in the **sun-visor**, on the charging station (on the side) **at this „RFID“ symbol.**



3. when the button is turning „RED“ (see illustration) the loading process was started successfully.

Erklärung der Leuchtanzeigen für die Ladepunkte Explanation of charge point lights					
		Ladepunkt deaktiviert Charge point not activated			Ladepunkt aktiviert, Fahrzeug lädt Charge point activated, charging in process
		Ladepunkt bereit Charge point on standby			Ladepunkt aktiviert, Fahrzeug lädt nicht Charge point activated, vehicle is not charging
		Authentifizierungsanfrage läuft Authentication in progress			Ladepunkt nicht bereit, Fehler erkannt Charge point not on standby, error detected

4. COMPLETE 😊

Dear ladies & gentlemen!
The TIWAG charging card is used for opportunity charging (in Tyrol & Carinthia) outside the FLUGS location.

(see SUN-VISOR)

Plug in the loading cable, hold on the **Tiwag charging card** on symbol, wait until the **button turns red** , after that the loading process is going to start.

For loadings outside of this region we recommend the loading-App:

EnBW mobility+
EnBW AG